

How to measure Sanitary Fittings

Things you need to know

TriClamp Size is determined by the outside diameter of the pipe, NOT the outside diameter of the ferrule.


The ferrule (the end pieces that get clamped together with a gasket) is about 1/2" larger than the pipe size. In other words, a 1.5" fitting will have a ferrule whose outside diameter is about 2".



The tables below shows how to measure standard fittings.

Tri Clamp Size	Ferrule I.D.	Ferrule O.D.
1.5"	1.37"	2"
2"	1.87"	2.5"
2.5"	2.37"	3"
3"	2.87"	3.5"
4"	3.83"	4.5"

The same is true for the Bevel Seat fittings



Bevel Size	Actual O.D.
1.5"	1.85"
2"	2.37"
2.5"	2.9"
3"	3.4"
4"	4.5"



ORDER ONLINE AT
www.partsdeptonline.com

CALL: 1-800-245-8222
 FAX: 860-364-9354

